

INSTALLATION INSTRUCTIONS FOR SA AND GP FUNCTIONS 205 AND 211

DOOR PREPARATION

- A. Mark height line on edge of door.
Suggested height from floor is
38" to 40⁵/₁₆".

NOTE: A drill guide is recommended on
all holes to ensure alignment.

- B. Using template supplied, fold over
edge of door, center on height line
and mark the centers for the two
 $\text{Ø}^{5}/_{16}$ " holes. Note that the template
is used for multiple locks; do not bore
the $\text{Ø}2^{1}/_{8}$ " hole,
BORE ONLY THE TWO $\text{Ø}^{5}/_{16}$ " HOLES,
center-to-center distance 2³/₄" (69.8mm).

205 INSTALLATION

- A. Remove the lever and rose scalp from
the Inside trim (side with short bushings).
- B. Place outside trim on door inserting the
bushings in the $\text{Ø}^{5}/_{16}$ " holes.
- C. Install outside trim using two thru door
screws (M5 x 0.8 x 60mm) into the thru bolt
bushings of the outside trim.

- D. Install the inside rose scalp, making sure
that the tabs on the rose scalp snap
firmly into the cutouts on the rose
plate.
- E. Install inside lever and tighten the set
screw.

211 INSTALLATION

- A. Place lever assembly on door.

- B. Install two thru door screws
and finishing washers.

